#### www.orphancameras.com

This manual is for reference and historical purposes, all rights reserved.

This page is copyright© by M. Butkus, NJ.

This page may not be sold or distributed without the expressed permission of the producer

I have no connection with any camera company

On-line camera manual library

This is the full text and images from the manual. This may take 3 full minutes for the PDF file to download

If you find this manual useful, how about a donation of \$3 to: M. Butkus, 29 Lake Ave., High Bridge, NJ 08829-1701 and send your e-mail address so I can thank you. Most other places would charge you \$7.50 for a electronic copy or \$18.00 for a hard to read Xerox copy.

This will allow me to continue to buy new manuals and pay their shipping costs.

It'll make you feel better, won't it?

If you use Pay Pal or wish to use your credit card,

click on the secure site on my main page.

# Nikon []][]

Instruction Manual (P.2-P.31)
Bedienungsanleitung (S.32-S.61)
Manuel d'utilisation (P.62-P.91)
Manual de instrucciones (P.92-P.121)
使用說明書 (P122~151)

使用说明书 (P152~181)

3

G

3

S

C

# **English**

Thank you for purchasing the Nikon FE10 camera. The FE10 is a compact, light weight manual focus SLR camera incorporating a TTL full-aperture exposure metering system. This feature enables automatic and manual exposure control operations for a wide range of shooting situations. Be sure to read this instruction manual thoroughly before use, and keep it close at hand until you have fully mastered the camera's operation.

#### Take some trial shots.


Before taking important pictures, be sure to take a few trial shots first to familiarize yourself with the camera and all its features.

—Nikon cannot be held responsible for malfunctions caused by using the FE10 in ways not specified in this manual.

### Attaching the neckstrap

Attach the neckstrap (provided) as shown in the figure below.

- 1 Thread the triangle ring through the neckstrap eyelet and attach the strap.
  - —Make sure the tip of the strap comes through on the inside of the strap.
- 2 Adjust the length as shown.
  - —Adjust the length by pulling one end of the strap with the help of the black plastic ring provided.



#### www.orphancameras.com


# **Contents**

Attaching the neckstrap ·····	2
Contents	3
Nomenclature	4-5
Installing the batteries	6
Checking battery power	
Loading the film ·····	8-9
Setting ISO film speed	10
Focusing	11
Determining correct exposure (Aperture-price	
automatic exposure mode)	
Using the AE-L (lock) button	14
Exposure compensation with ISO/film	
speed set ring	15
Determining correct exposure	
(Manual exposure mode)	
Depth-of-field preview	18

Rewinding the film	19
B (bulb) setting ·····	20
Film plane indicator ·····	
Self-timer operation	
Flash photography ······	
Holding the camera properly	
Multiple exposure photography	
Infrared photography	
Mounting and removing the lens	
Compatible lenses	
Optional accessories ······	
WARNING	
Camera care tips	
Notes on batteries ······	
Specifications	
Оробіновногіз	

### **Nomenclature**

- 1 Shutter speed index
- 2 Shutter speed dial
- 3 Shutter speed dial lock button
- 4 Film advance lever
- 5 Shutter release button
- 6 Multiple exposure lever
- 7 Frame counter
- 8 Self-timer button
- 9 Neckstrap eyelet
- 10 Depth-of-field preview lever
- 11 Hand grip
- 12 Aperture ring
- 13 Zoom ring
- 14 Focusing ring
- 15 Hot shoe contact/ accessory shoe
- 16 Film plane indicator
- 17 Film rewind crank
- 18 Film speed lock lever
- 19 ISO/film speed indicator/ exposure compensation indicator
- 20 ISO/film speed set ring
- 21 AE-L (lock) button
- 22 Lens release button
- 23 Distance scale



15

16

19


20

21

22

23

#### www.orphancameras.com




# Installing the batteries

**Caution:** Keep batteries out of children's reach. If someone accidentally swallows a battery, call a doctor immediately.

Use two alkaline batteries (LR44), two silver batteries (SR44) or one lithium battery (CR-1/3N).

Note: Be sure to set the shutter speed dial to L (lock) when replacing batteries.


- Unscrew the battery chamber lid (31) counterclockwise using a small coin or similar object.
- Place the batteries into the battery holder on the back of the battery chamber lid.
  - —Make sure that the "+" signs are lined up according to the indications on the side of the battery chamber lid.
- **3** Put the battery chamber lid back in its place and screw it in clockwise.



### **Checking battery power**


- 1 Wind the film advance lever (4).
- **2** Set the shutter speed dial to any position other than L (lock).
- **3** While lightly pressing the shutter release button (5), look through the viewfinder eyepiece (26).
  - —If any one of the three red LED indicators lights up, the camera is functioning normally. If none of the indicator lamps light up, either the battery is improperly installed or battery power is exhausted.
  - —If battery power is exhausted, replace both batteries with fresh ones.


**Note:** Set the shutter speed dial to L when the camera is not in use to preserve battery power and prevent accidental shutter release.



# Loading the film

- Avoid loading or unloading the film in direct sunlight.
- Do not touch the shutter curtains with your finger or with the film leader when loading or unloading the film.
- 1 Pull out the film rewind knob (28) to open the camera back.
  - —The frame counter (7) is reset to "S" when the camera back is opened.
- Install the film cartridge.
  - —Place the film cartridge in the film cartridge chamber (30) with the protruding part pointing downward.
- 3 Push the film rewind knob back down.
- 4 Pull the film leader across and insert it into one of the slots in the film takeup spool (24). Rotate the film takeup spool inward, making sure the latch in the slot engages the first or second perforation along the side of the film leader.







5 Wind the film advance lever to advance the film.

—Check to ensure the film is properly positioned between the film guide rails (27) and make sure that the film sprockets (25) engage the perforations on the edge of the film.

- 6 Gently close the camera back until it clicks shut.
- **7** Slowly rotate the film rewind crank in the direction of the arrow to take up film slack.
  - Rotate the crank until there is no more slack and rotation becomes difficult.
- Press the shutter release button and wind the film advance lever (blank exposures) until the frame counter reaches frame "1".
  - —Confirm that the film rewind knob rotates counter-clockwise as you wind the lever, indicating that the film has been loaded and advanced correctly.
  - -Slowly and securely wind the film advance lever.







# Setting ISO film speed

Check the film cartridge box or enclosed notice for ISO film speed numbers.

- While sliding the film speed lock lever in the direction of the arrow, rotate the ISO/film speed ring (20).
- Align the ISO/film speed indicator with the ISO value of the film in use.
  - —To perform the above operation correctly, the ring must click into position. Correct exposure cannot be obtained unless the film speed is set properly.
- 3 Remove your finger from the film speed lock lever to lock the ISO/film speed set ring.





### **Focusing**


The FE10 comes with a "K" focusing screen suitable for general photography, allowing three focusing aids: (A) Split image focusing, (B) Microprism focusing, and (C) Matte field focusing.


—Choose the most effective focusing aid depending on the shooting situation, lens used, subject, etc.

# 1 Look through the viewfinder and rotate the focusing ring.

- —When focusing with the split image spot, turn the focusing ring until the image in the two halves becomes whole. When the upperand lower-half images are not in alignment, the subject is out of focus.
- —When focusing with the microprism collar outside the center spot, turn the focusing ring until the shimmering image appears sharp.
- —When focusing with the entire matte field, turn the focusing ring until the image looks sharp.

**Note:** As the FE10 viewfinder covers approx. 93% of the image area, the final picture area will be somewhat larger than the image in the viewfinder.





# Determining correct exposure


# Aperture-priority automatic exposure mode (suitable for portrait or landscape photography)

In this mode, the camera automatically sets the proper shutter speed corresponding to the brightness of the main subject by presetting the aperture.

Choose a suitable aperture value based on the brightness of the main subject, the desired depth-of-field and the speed of the film in use. Suggested aperture settings with ISO 100 film are shown in the table.

- While pressing the shutter speed dial lock button, rotate the shutter speed dial and align "A" with the shutter speed index.
- 2 Rotate the lens aperture ring in either direction to align the desired aperture value with the aperture index.

Main subject	Aperture (f/value)		
In subdued light	f/1.4 to f/2		
To narrow depth-of-field	f/1.4 to f/2		
To deepen depth-of-field	f/11 to f/16		
Indoors in normal conditions	f/2 to f/4		
Outdoors on a cloudy day	f/4 to f/8		
Outdoors on a fine day	f/8 to f/11		
Seaside in midsummer	f/11 to f/16		



www.orphancameras.com

3 Look through the viewfinder and lightly press the shutter release button.

—The red LED indicator lamps inside the viewfinder light up next to the "A" mark and the suggested shutter speed.

—The red LED indicator next to the shutter speed scale moves up and down depending on the subject brightness and the aperture selected.


—If the red LED indicator lamp lights up next to 2"-8", shutter speed is set to approx. 2 to 8 sec.

—If the red LED indicator lamp blinks at the "2000" mark, the main subject is too bright and overexposure will result. Choose a smaller aperture (higher f/value).

—The red LED indicator lamps remain lit inside the viewfinder for approx. 20 seconds after you remove your finger from the shutter release button.

—LED indicator lamp does not appear if the film has not been advanced.

**Note:** Use a tripod and/or cable release to minimize camera shake if the LED indicator lamp indicates a shutter speed value smaller than that of the focal length of the lens in use; for example if the LED indicator lamp shows 125 (1/125 sec.) or slower with a 135mm lens mounted. This applies even if the lens is set at its maximum aperture.




- 1 A (Auto)
- ② Sync shutter speed
- 3 Shutter speed scale
- (4) 2"~8"
- (5) B (Bulb)

# Using the AE-L (lock) button

In aperture-priority automatic exposure mode, when there is substantial difference in contrast between the main subject and the background, or the overall scene is unusually light or dark in tone, the photograph may be overexposed or underexposed. To ensure proper exposure, determine the correct exposure for the main subject and use the AE-L (lock) button.

- 1 Move the camera to center the main subject inside the viewfinder or move in closer until most of the viewfinder is covered by the subject.
- 2 Focus on the main subject.
- 3 Lightly press the shutter release button, and confirm that the red LED indicator lamp inside the viewfinder is lit. After lightly pressing the shutter release button, press the AE-L (lock) button.




- —When the AE-L (lock) button is pressed, exposure is locked, and it remains locked as long as the LED indicator lamp blinks next to "A".
- —Approx. 20 seconds after removing your finger from the AE-L (lock) button, the red LED indicator lamp next to "A" stops blinking, and AE-L (lock) is canceled.
- —Exposure cannot be locked if you press the AE-L (lock) button without also pressing the shutter release button halfway.
- 4 Recompose, focus on the subject and shoot.
  - —When the shutter is released, the AE-L (lock) is automatically canceled.
  - —Press the AE-L (lock) button again to cancel the AE-L (lock) before shooting.


# Exposure compensation with ISO/film speed set ring

In cases such as those described in "Using the AE-L (lock) button" above, you can perform exposure compensation within a range of ±2 steps (in 1/3 increments) by turning the ISO/film speed set ring.

	Exposure compensation possible						
Film speed	ISO 25	ISO 50	ISO 100-800	ISO 1600	ISO 3200		
+ direction	0	+1 step	+2 steps	+2 steps	+2 steps		
- direction	-2 steps	-2 steps	_2 steps	-1 step	0		

- While sliding the film speed lock lever in the direction of the arrow, rotate the ISO/film speed ring (20).
- Align the exposure compensation indicator with the appropriate compensation value.
  - —To perform the above operation correctly, the ring must click into position. Correct exposure cannot be obtained unless exposure compensation is set properly.
- Remove your finger from the film speed lock lever to lock the ISO/film speed set ring.






### **Determining correct exposure**

#### Manual exposure mode

Suggested shutter speed settings with ISO 100 film are shown in the table.

- —With bright subjects, fast moving subjects or high ISO film speeds, select a higher shutter speed.
- —Select a higher shutter speed to minimize camera shake when using a telephoto lens.
- 1 Rotate the shutter speed dial (2) to align the desired shutter speed number with the shutter speed index (1).
  - —To rotate the dial from the "A" setting, depress the shutter speed dial lock button.
  - —Note that intermediate shutter speeds between the printed numbers cannot be used. Be sure to rotate the shutter speed dial until it click-stops otherwise a correct shutter speed cannot be obtained.
  - When using the B (bulb) setting, the exposure display does not work.
  - —When set to L (lock) position, the shutter is locked.


Main subject	Shutter speed (sec.)		
Stationary subjects in subdued light	1 to 1/15		
Indoors in normal conditions	1/30 to 1/60		
Outdoors on a fine day	1/125 to 1/250		
Seaside in midsummer	1/500 to 1/2000		
Mountain area with snow	1/500 to 1/2000		
Fast moving subjects	1/500 to 1/2000		




—On the shutter speed dial: "2000" means 1/2000 sec., "1" means 1/1 sec., and "B" means bulb.

- 2 Look through the viewfinder and lightly press the shutter release button.
  - —The red LED indicator lamp inside the viewfinder blinks next to the recommended shutter speed.
  - —The red LED indicator lamps remain lit inside the viewfinder for approx. 20 seconds after you remove your finger from the shutter release button. Should you press the AE-L (lock) button after lightly pressing the shutter release button, the red LED indicator lamps will stay lit for another 20 seconds.
- 3 Rotate the aperture or shutter speed dial and align the red LED indicator lamp with the blinking lamp inside the viewfinder.
  - —Once the two LED indicator lamps merge, the blinking stops and you can obtain a correct exposure.
  - —In manual exposure mode, the shutter speed changes by one-stop. If the LED indicator lamps inside the viewfinder light up and blink at an aperture less than one f/stop, select a half f/stop on the lens aperture ring.

**Note:** When shooting extremely light or dark subjects, the correct exposure display cannot appear because the subject exceeds the camera's metering range of EV1–EV18.





Exposure value (EV) is a number representing a variable combination of shutter speed and aperture producing the same exposure effect when the scene brightness and ISO remain the same.

At ISO 100, a shutter speed of 1 second at f/1.4 is defined as EV1. If the aperture is stopped down by one full f/stop (or the shutter speed is one step faster), the EV increases by one; if the aperture is opened up by one full f/stop (or the shutter speed is one step slower), the EV decreases by 1. For example, using ISO 100, 1 sec. at f/2 is EV2, 1 sec. at f/5.6 is EV5, while 1/125 sec. at f/8 is EV13. As the exposure is the same, 1/125 sec. at f/8 and 1/250 sec. at f/5.6 are also EV13.


### Depth-of-field preview

Depth-of-field is the in-focus area behind and in front of a subject. Depth-of-field preview enables you to check the depth-of-field at any given aperture by looking through the viewfinder for creative effect.

- 1 Set the aperture to the desired f/stop, and depress the depth-of-field preview lever (10).
- **2** Look through the viewfinder and check the depth-of-field.

#### Note

- Fully depress the depth-of-field preview lever.
- Do not release the shutter or advance film while depressing the preview lever; as it may cause improper exposure or camera malfunction




### Rewinding the film

Avoid rewinding or unloading film in direct sunlight.

- 1 Toward the end of a roll of film, check the frame counter (7) as you rewind the film.
  - —If the frame counter shows that all frames have been exposed, rewind the film.
- **2** Press the film rewind button (36) on the camera base.
  - —You don't have to keep pressing, once is enough.
- 3 Lift the film rewind crank (17) and turn it in the direction of the arrow.
  - —When the crank feels lighter and there is no more resistance, the film is fully rewound.
- 4 Pull the film rewind knob to open the camera back. Remove the film cartridge.
  - —Do not open the camera back until the film is fully rewound, otherwise light comes into the camera, exposing the film.

**Note:** If the film reaches the end of the roll while you are advancing the film, the film advance lever will lock. Stop trying to advance the film. Rewind the entire roll, then complete the movement of the film advance lever and set it back into position.






# B (bulb) setting


This setting is useful when an exposure longer than one second is required, such as in landscape photography at night.

- Use of a tripod and/or cable release is recommended.
- Be sure to attach the optional eyepiece cover DK-5 when you shoot with your eye away from the viewfinder to prevent stray light from entering the viewfinder and affecting exposure.
- The self-timer does not work in B setting.
- Set the shutter speed dial to B.
- **9** Depress the shutter release button.
  - —The red LED indicator lamp lights up next to "B" inside the viewfinder.
  - —The shutter remains open as long as the shutter release button is depressed.
- When film has been exposed for a predetermined period of time, remove your finger from the shutter release button to stop B (bulb) operation.



## Film plane indicator

The film plane indicator shows the exact position of the film plane inside the camera and is used to measure the distance between subject and film plane, such as in macrography.




### Self-timer operation

- **1** First compose the picture and check the focus, then press the self-timer button (8).
  - —The self-timer indicator lamp blinks for 8 sec., then stays lit for 2 sec. before the shutter is released.

#### Note

- To cancel self-timer operation after it has been selected, press the shutter release button or set the shutter speed dial to "L".
- The self-timer can be used with any shutter speed except for B (bulb).
- You can use the self-timer instead of a cable release to prevent camera shake during shutter release.



# Flash photography

Mount the Nikon speedlight on the camera's hot shoe contact/accessory shoe (15).

—For more details, refer to the instruction manual provided with each speedlight.

# 1 Set the shutter speed dial to "A", or 1/60 sec. or slower.


- —Lightly press the shutter release button, the red LED indicator lamp (next to X90 or shutter speed set) inside the viewfinder light up.
- —When the shutter speed dial is set to "A" or set manually between 1/2000 and 1/125 sec., sync shutter speed is automatically switched to X90 by turning ON the speedlight power. With the shutter speed dial set manually between 1/60 and 1 sec., flash output is controlled at the shutter speed set.


### **9** Set the aperture.

- —When using a speedlight in auto flash mode, set the aperture value specified in the instruction manual of the speedlight.
- —When using a speedlight in manual flash mode, select an aperture value by using the following equation.

Aperture (f/stop) = 
$$\frac{\text{guide number (GN)}}{\text{flash-to-subject distance (m)}} \times \sqrt{\frac{\text{ISO}}{100}}$$

**Note:** Do not use flash units made by other manufacturers since the camera may not work correctly.





# Holding the camera properly

- Use your left hand to cradle the bottom of the camera, with your thumb and index fingers wrapped around the focusing ring of the lens so that you can rotate it.
- Hold the hand grip lightly with your right hand, use your index finger of your right hand to depress the shutter release button.
- Keep your elbows in against the body, and steady the camera against your forehead as you look through the viewfinder eyepiece.


**Note:** Use of a tripod and/or cable release is recommended to minimize camera shake when using a telephoto lens or selecting slow shutter speeds.



# $\label{eq:multiple} \textbf{Multiple exposure photography}^{\text{www.orphancameras.com}}$

Overlapping several images on the same frame can produce special creative effects.

- Press the shutter release button to take the first shot.
- 2 While pulling the multiple exposure lever (6) as far as it will go, wind the film advance lever fully.
  - -Make sure that the frame counter does not advance.
- 3 Press the shutter release button to take the second shot.



- Repeat steps "2" and "3" above to take any number of multiple exposures.
  - —In multiple exposure photography, since several exposures are taken on the same frame, correct exposure is an aggregate of each successive exposure. We recommend using exposure compensation when the main subject overlaps over the background. Refer to the following values as a guide.
    - 2 exposures: -1.0 3 exposures: -1.5 4 exposures: -2.0

Take a few test shots. If the background of the first shot is totally dark, and the subject of the next shot does not overlap another subject within the frame, as a rule exposure compensation is not necessary.

#### Note


- Do not touch the multiple exposure lever when advancing film unless taking multiple exposures.
- In multiple exposure photography, the FE10 is designed to reduce film dislocation to the minimum. But it may occur due to film curling, film slack or inappropriate film winding.
- Before having your pictures developed, we recommend informing the photo lab that some multiple exposures are included in the film.


# Infrared photography

When using infrared film and filters, note that the plane of sharpest focus is slightly farther away than in visible-light photography. You can compensate for this shift in focus by referring to the infrared compensation index (green or yellow index with red line) on the lens barrel.

**Note:** For further details on infrared photography, refer to the instruction manual provided with the infrared film.


- 1 Look through the viewfinder with no filter attached, and focus on the subject.
- **2** Read the focus distance and rotate the focusing ring to align it with the infrared compensation index.
  - —Align the distance with the green index for a 35mm (wide) side.
     —Align the distance with the yellow index for a 70mm (telephoto) side.
- **3** Be sure to attach the appropriate filter, such as an R60, etc. and take the shot.





# Mounting and removing the lens

- Avoid mounting or removing the lens in direct sunlight.
- Do not press the lens release button when mounting the lens.
- 1 Align the lens mounting index (white) on the camera body with the focusing index on the lens, and twist the lens counter-clockwise.
  - —Rotate the lens until it clicks into place.
- 2 To remove the lens, push the lens release button (22) and rotate the lens clockwise until the lens comes off.



### **Compatible lenses**

Al-type Nikkor lenses, AF Nikkor lenses, Nikon Series E lenses, Reflex Nikkor lenses, and Medical-Nikkor lenses can be mounted on the Nikon FE10 camera. Other Nikkor lenses are not compatible because these lenses do not make contact with the FE10's meter coupling lever on the camera body, and some lenses simply cannot be mounted on the camera. (Do not try to mount these lenses on the camera, as the lens may become stuck and the camera body may be damaged).

#### The following non-Al-type Nikkor lenses can be used:

- Reflex Nikkor 500mm f/8 lens
- PC-Nikkor 28mm f/3.5 lens
- Medical Nikkor 120mm f/4 lens

# Optional accessories

#### Speedlights

Nikon Speedlights SB-27, SB-26, SB-22, and SB-16B can be used with the FE10. Speedlights are convenient for shooting in dim light or taking backlit portraits.

- The above Nikon Speedlights can be mounted directly onto the FE10's built-in hot shoe with no sync cord connected.
- With these Speedlights, flash photographs can be taken in non-TTL auto flash or manual flash modes. (For further details, read the instruction manual provided with each speedlight.)

#### Close-up equipment

Attach close-up lenses No. 0, No. 1 and No. 2 to the front of the lens. The Auto Extension Rings PK-11A, PK-12, PK-13, and Bellows Focusing Attachment PB-6 are attached between the lens and the camera body.

#### Viewfinder accessories

Rubber eyecup (square), eyepiece correction lenses (9 types), eyepiece adapter, eyepiece magnifier DG-2, eyepiece cover DK-5, and cable release AR-3 fit onto the viewfinder eyepiece or the camera body.

### **Notes on batteries**

- If the camera is not in use for a long time, remove the batteries from the camera body to protect the camera from leakage of battery corrosion and keep them in a cool, dry place below 20°C (68°F).
- When using exhausted batteries in cold temperature, the exposure display may not work. Use fresh batteries
  or carry spare batteries, keeping them warm alternately, when taking pictures in cold temperature. Weakened
  battery power due to a drop in temperature usually recovers when the temperature comes back to normal.
- Turn the camera power OFF when replacing the batteries. Make sure the battery terminals (+), (-) are
  correctly oriented.
- Do not disassemble, short-circuit, heat or throw used batteries into a fire, as an explosion may result.
- When replacing batteries, be sure to replace all the batteries at the same time. Always use fresh batteries of the same brand, otherwise battery life may be shortened or poor contact may result.

# **Specifications**

Type of camera:	Electronically-controlled 35 mm single-lens reflex (SLR) focal plane shutter camera	Film advance:	By single lever-action. Double film advance and double exposure prevent mechanism provided.
Exposure mode:	Aperture-priority auto / manual exposure modes	Multiple exposure:	Provided via lever
Exposure metering:	Through-the-lens (TTL), center-weighted, full-aperture, stop-down exposure measurement	Film rewind:	By crank provided after film rewind button is pressed. (Film rewind button is automatically reset when film
Metering range:	EV1 to EV18 (1 sec. at f/1.4 to 1/2000 sec. at f/11 using		advance lever is wound.)
	50mm f/1.4 lens)	Frame counter:	Additive type; automatically resets to "S" when camera
Usable film:	Any cartridge-type 35 mm film		back is opened.
Picture format:	24 mm × 36 mm	Film speed range:	ISO 25 to 3200, in 1/3 steps with lock (ISO 100, 400
Lens mount:	Nikon F bayonet mount		(red) in manual mode)
Shutter:	Electronically controlled vertical-travel metal focal plane	Exposure	
	shutter	compensation:	By ISO/film speed set ring within a range of ±2
Shutter speeds:	8 to 1/2000 sec. in A (auto) mode; 1 to 1/2000 sec. and B (bulb) in manual mode		steps (in 1/3 increments) for film speeds ranging from ISO 100 to 800.
Sync shutter speed:	Automatically set to 1/90 sec. in auto mode (LED	AE-L (lock):	Via AE-L (lock) button in A mode
cyno onacco apocar	indicator lamp lights up next to X90 in the viewfinder.) 1/60 sec. or slower set manually (automatically switches	Self-timer:	Electronic self-timer with 10 sec. shutter release delay, cancelable by pressing shutter release button again
	to X90 when the shutter speed is set to between 1/2000	Hot shoe contact/	
	and 1/125 sec.)	accessory shoe:	Hot shoe only (with ready-light contact provided)
Viewfinder:	Eye-level pentaprism type; approx. 0.84x magnification	Depth-of-field preview:	Provided: via lever on front of camera
	with 50mm lens set at infinity; approx. 93% frame	Tripod socket:	1/4 inch
	coverage.	Power source:	Two 1.5V alkaline batteries (LR44), two silver batteries
Viewfinder display:	16 red LED indicator lamps (lighting up or blinking).		(SR44) or one 3V lithium battery (CR-1/3N)
	Shooting mode: A, X90, or B. AUTO: LED lights up next to shutter speeds of 1/2000 to	Power switch:	Power is turned OFF by setting the shutter speed dial to L Turned ON by pressing shutter release button halfway.
	1 sec., and 2"~8" (in 13 steps). Manual: LED lights up at 1/2000 to 1 sec. (12 steps) and B.	Battery power check:	Press shutter lightly: red LED lamps light up indicating normal function.
	Overexposure warning: LED blinks next to 1/2000	Dimensions (W×H×D):	Approx. $139 \times 86 \times 53 \text{ mm} (5.5 \times 3.4 \times 2.1 \text{ inch})$
Focusing screen:	Split-image microprism type (Type K)		): Approx. 400g (14.1 oz)
Mirror:	Quick-return type	,	

#### For F-401x/N5005\* Users


This sheet will help you use your Speedlight (SB-20, SB-22, SB-23 or SB-24) with the Nikon F-401x/N5005 camera. The following shows instructions for Speedlight set at TTL flash exposure mode. For other flash exposure modes, specifications, accessories and miscellaneous, see instruction manual of each Speedlight, referring to F-401/N4004 or F-401s/N4004s model. \* The Nikon N5005, N4004s, and N4004 are sold exclusively in U.S.A.

This sheet uses the SB-22 Speedlight (and SB-24, in one example,) for demonstration purposes.

Matrix Balanced Fill-Flash—Operation in programmed auto, shutter-priority auto or aperture priority auto [ 2 ]

www.orphancameras.com

 If subject brightness is insufficient, the viewfinder ready-light blinks to suggest that you use a flash.



2. Turn on Speedlight.

# Automatic balanced fill-flash

As mentioned on page 48 of the F-401x/N5005 camera's instruction manual, Speedlight's TTL flash exposure control lets you perform automatic balanced fill-flash—Matrix Balanced Fill-Flash and Center-Weighted Fill-Flash. Note that you cannot perform programmed TTL auto flash shooting with the F-401x/N5005 camera.


Procedures for automatic balanced fill-flash operation with your external Speedlight, shown in the following, are very similar to those with camera's built in TTL flash. However, some specifications are different from those for built-in TTL flash.

- Usable film speed range for TTL flash shooting with an external Speedlight is ISO 25 to ISO 1000 (up to ISO 800 with built-in TTL flash).
- Controlled shutter speed/aperture is the same as with built-in TTL flash, however, controlled maximum apertures for programmed auto and shutter-priority auto with an external Speedlight are as follows:


ISO film speed	25	50	100	200	400	800	1000
Controlled max. aperture	f/4	f/4.7	f/5.6	f/6.7	f/8	f/9.5	f/10

• Flash shooting distance range, which depends on each flash's guide number also differs from that of built-in TTL flash. (See the following).

#### www.orphancameras.com



- **3.** Set Speedlight's mode selector to TTL.
  - With SB-23, setting mode selector to TTL simultaneously turns Speedlight on.



4. Compose picture and lightly press shutter release button. In programmed auto exposure mode, no exposure indicator LED lights up inside the viewfinder. In shutter-priority auto or aperture-priority auto, confirm o lights up.


If +, +0, - or 0- lights up\* (in shutter-priority auto and aperture-priority auto only), over- or underexposure may occur for background. To avoid this:

In shutter-priority auto:
Select faster or slower shutter
so that + or - disappears


and only o lights up.

In aperture-priority auto:
Select smaller aperture (larger f-number) or larger aperture (smaller f/number) so that + or - disappears and only olights up.

\* With a flash, the shutter will not lock even if + or lights up.




With SB-24: Using the SB-24's adjust button, set on controlled aperture SB-24's LCD panel to read flash shooting range.




With SB-20, SB-22, or SB-23: Read flash shooting range from Speedlight's aperture selection/ shooting distance range panel.

5. Make sure subject is within the flash shooting distance range. To read the flash shooting distance range in programmed auto or shutter-priority auto, first obtain the controlled aperture value shown in the table at right.

#### www.orphancameras.com







- Confirm ready-light is on, then fully depress shutter release button to take a shot with the flash
  - With ready-light off, flash is charging and shutter remains locked.

If ready-light blinks for a few seconds after shooting: The flash has fired at its maximum output and light might be insufficient. Confirm shooting distance and, if necessary, move closer to the subject or switch exposure mode to aperture-priority auto to select a wider aperture.

#### www.orphancameras.com

#### To obtain controlled aperture value in programmed auto and shutter-priority auto

In programmed auto		In shutter-priori	In shutter-priority auto		
For subjects backlit by the sun	f/16	For subjects backlit by the sun	f/16 at 1/125 sec.		
For outdoor subjects on a sunny day	f/8	For outdoor subjects on a sunny day	f/8 at 1/125 sec.		
For outdoor subjects on a cloudy day/in shadows	f/5.6	For outdoor subjects on a cloudy day/in shadows	f/5.6 at 1/125 sec.		
or for indoor subjects		For indoor subjects	f/5.6 at 1/30 sec.		

The listed aperture values should only be used as a guide. To choose desired aperture, switch exposure mode to aperture-priority auto or manual.

# Center-Weighted Fill-Flash — Operation in manual exposure mode

In manual exposure mode, the ready-light does not appear to recommend flash use. Turn the Speed-light and follow the procedure for Matrix Balanced Fill-Flash operation, step 3 to step 6. However, to choose the desired brightness level in the scene center the viewfinder 12mm-dia. circle on the area where you desire a correct exposure before lightly pressing the shutter release button and recompose as desired after confirming the exposure indication.